

# SBSef 7242

Side-by-Side combination  
Comfort

# LIEBHERR

Freestanding



Skef 4260

Freestanding refrigerator  
Comfort



← 60 →



Frequency / voltage	50/60 Hz / 220-240 V~
Connection Rating	1.2 A
Door / Side walls	SmartSteel / silver
Exterior dimensions in cm (h / w / d)	185.2 / 60 / 62.3 <sup>1</sup>
<b>Controls</b>	
Type of Control	MagicEye behind-the-door, touch electronic Digital temperature display
Door alarm	acoustic
Alarm in case of malfunction	visual and acoustic
<b>Fridge compartment</b>	
Forced air system	PowerCooling
Door interior	Comfort GlassLine storage shelves with bottle holder, egg tray
Bottle shelf	Bottle shelf
Interior light	LED ceiling lighting
Fruit and vegetable bins	2 fruit and vegetable drawers on telescopic rails
<b>Features</b>	
Side-by-Side concept	Side-panel heating on both sides, suitable for combination with other fridges, freezers and/or wine appliances
Door hinges	Fixed door hinge, right
EAN-Nr.	-

<sup>1</sup> To achieve the indicated energy consumption level, the wall spacers provided with the appliance must be used. These increase the appliance depth by approximately 3.5 cm. If the wall spacers are not used, the appliance will remain fully functional, but will have a slightly higher energy consumption level.

## Features

---



### SmartSteel

SmartSteel significantly reduces the visibility of finger marks and is very easy to clean.



### Bottle rack

The bottle rack is a solution for storing beverages which is both practical and pleasing to the eye. Here bottles can be stored within a compact space.



### SuperCool

The automatic SuperCool function lowers the refrigerator temperature down to as far as  $+2^{\circ}\text{C}$  for as long as 12 hours - ideal for rapidly cooling freshly stored food.



### Door alarm

The audible door alarm alerts the user if the door has been open for longer than 60 seconds for safe protection of the food.



### Child lock

The child lock is programmed so as to prevent the appliance being inadvertently switched off. A symbol in the MagicEye indicates when the child lock is switched on.



### Transparent vegetable bins

Transparent vegetable bins provide plenty of space for the organised storage of fruit and vegetables. In addition, they are easy to clean.



SGNef 3036

Freestanding freezer with NoFrost  
Comfort



← 60 →



Frequency / voltage	60 Hz / 220 V~
Connection Rating	1.3 A 259 W
Door / Side walls	SmartSteel / silver
Exterior dimensions in cm (h / w / d)	185.2 / 60 / 62.3 <sup>1</sup>
<b>Controls</b>	
Type of Control	MagicEye behind-the-door, touch electronic Digital temperature display
Door alarm	acoustic
Alarm in case of malfunction	visual and acoustic
<b>Freezer compartment</b>	
Number of drawers	8 drawers, of which 1 herb and berry tray, VarioSpace
VarioSpace	yes
<b>Features</b>	
Side-by-Side concept	Side-panel heating on both sides, suitable for combination with other fridges, freezers and/or wine appliances
Door hinges	Fixed door hinge, left
EAN-Nr.	-

<sup>1</sup> To achieve the indicated energy consumption level, the wall spacers provided with the appliance must be used. These increase the appliance depth by approximately 3.5 cm. If the wall spacers are not used, the appliance will remain fully functional, but will have a slightly higher energy consumption level.

## Features




### NoFrost

Liebherr's NoFrost appliances provide expert refrigeration technology to ensure long-term freshness. The food is frozen with chilled recirculating air, and any humidity is expelled. As a result, the freezer is always free of ice, and food no longer frosts over. NoFrost convenience makes defrosting a thing of the past.



### SmartSteel

SmartSteel significantly reduces the visibility of finger marks and is very easy to clean.



### Automatic SuperFrost function

The automatic SuperFrost function makes freezing simple and saves energy. It quickly reduces the temperature to -32 °C and thus creates the cold air required to preserve vital vitamins. As soon as the food is completely frozen, the automatic SuperFrost function switches back to normal mode after max. 65 hours, and thus assists in saving electricity.



### Door alarm

The audible door alarm alerts the user if the door has been open for longer than 60 seconds for safe protection of the food.



### Child lock

The child lock is programmed so as to prevent the appliance being inadvertently switched off. A symbol in the MagicEye indicates when the child lock is switched on.




### FrostSafe

With the FrostSafe, the extra-high and removable drawers are closed all round. This means that the cold cannot dissipate so quickly when the appliance is opened. The transparent front of the compartments guarantees an optimum overview of the frozen items.

## Technical drawing

---



Products and their details are staged for advertising purposes. Whilst every effort is made to ensure all specifications and information in this flyer are accurate, Liebherr reserves the right to make changes without notification. Where actual appliance measurements, specifications, and ratings are crucial, we recommend that the actual appliance installation instructions that accompany each appliance be checked. Liebherr will not be liable for any damage. (11.02.2025)

